


Front



Back

These are instructions

Medical-grade silicone
5 speeds
Low-battery indicator
Waterproof IPX7
Travel lock
Universal USB-C
1-year warranty



Scan QR code and join our community of text subscribers for tips and tricks, product support, and exclusive emojibator offers.

How do I turn Emojibator on?

Please fully charge  your Peach before use. Peach has a battery life of 1 hour 10 minutes and a charge time of 1 hour 20 minutes. Peach has one button for  power and intensity. Press to turn on. Press to increase intensity. At the fifth intensity level, press to decrease intensity.

OMG I came. Turn this thing off.

Hold the  button for approximately three seconds at any setting to turn off.

How big is your peach?

That's not appropriate to ask, but I'll tell you anyway. The dimensions are approximately 3 inches in height, 2.6 inches in outer diameter, and 1.4 inches in inner diameter, making it the perfectly satisfying size.

Precautions: Do not use silicone-based lube with Peach. Do not clean with untested products containing alcohol, petroleum, or acetone. Do not boil, bake, or clean in the dishwasher. Do not insert anally; Peach's base is not flared for anal use. Do not use Peach if it is malfunctioning. This includes, but is not limited to, overheating, sparking, or if there is material damage

For questions, comments, or concerns, please email hello@emojibator.com or refer to our FFAQ page at emojibator.com.

Keep these instructions and use them as your new bookmark!

11.1cm x 8.4cm