

Meet

your new

toy.

Welcome to **Dame,**

your source for sexual exploration, education, and conversation. We design products for pleasure that help you connect with yourself, enhance sexual wellness, and promote collective wellbeing. Discover your new toy →

# Meet Pom

## Flexible Vibrator




Pom is a soft and supple vibe that delivers powerful pleasure from the palm of your hand. It envelops your vulva for full coverage and flexes with you for broad stimulation.

### Get to know Pom:



- 5 Intensities, 5 Patterns
- Medical-Grade Silicone (Phthalate-Free)
- USB-C Rechargeable
- Waterproof
- Whisper Quiet
- Travel lock
- Low-battery indicator
- 3-Year Warranty



Flexible Body



Intuitive Controls





## ← Using Pom

Please fully charge your Pom before use. Pom has three buttons: one for power and patterns, one to increase intensity, and one to lessen intensity.

**Hold** to turn on and off.


**Press** to cycle patterns.



You can change the intensity on any pattern in two ways:

**Hold** for steady intensity change.

**Press** for stepped intensity change.



# Charging Pom

Battery life (high intensity/steady mode): 1 hour

Charge time: 2 hours

The LED indicator is located under the power button. Plug the USB-C cable at the base of Pom to charge. LED will pulse while charging and will glow solid when fully charged.

Charging



Fully Charged



**Low-battery mode:** when Pom is at 25% charge, the toy will vibrate and the LED light will flash 5 times when switching the toy off.

---

## Travel Mode

Travel worry-free with Pom. Activate travel lock by holding the power button for 12 seconds. The LED light will flash 12 times then switch off to confirm the toy is locked. To deactivate, just plug Pom in to charge.

# Caring for Pom

Pom is waterproof. Clean your vibe after every use using either soap and water or a sex toy cleaner, like Dame's Hand + Vibe Cleaner. If using an alcohol-based cleaner, wait a few seconds for the alcohol to evaporate before using the toy. Dry thoroughly. Store separately from other toys, and away from extreme heat or cold.

---



## Caution

Do not use silicone-based lube with Pom.

Do not clean Pom with products containing petroleum or acetone.

Do not boil, bake, microwave, or clean Pom in the dishwasher.

Do not overbend.



---

## Questions?

Email: [support@dameproducts.com](mailto:support@dameproducts.com)

©2024 Dame Products Inc. dba Dame Products.

Dame Products and Pom are trademarks or registered trademarks of Dame Products Inc. All rights reserved



[Snap this code](#)  
to explore tips,  
and all things  
sexual health.